

Modular Kitchen Cabinets

Presents REV-A-SHELF

QUAD 27 QUART PULL-OUT WASTE CONTAINER PRODUCT # 4WCTM-27-4



Installation Instructions

To Install Quad 27 Quart Pull-Out Waste Container:

1. Install the rear bracket to the rear of the slide.
2. Install the front of slide to the cabinet face frame. The hole should be placed 3/8" from front of cabinet. The bottom of the slide should be 14 1/4" from cabinet floor. Use a #6 x 1/2" Low Profile Truss Head Screw.
3. If the rear of cabinet is thinner than 1/2", install a 1/2" x 3" wide furring strip to the back of cabinet, centered 14 1/4" from floor of cabinet.
4. Measure from inside cabinet wall to inside face frame. Distance should be measured the same at rear of cabinet.
5. Mount the rear bracket. Extend the slide rear-mounting bracket until it contacts the rear. The bottom of the slide should be 13 1/8" from cabinet floor. The rear mounting bracket should be the same distance from the side cabinet wall at rear of slides as it is up front. Drive the mounting screw in the center horizontal slot of the rear mounting bracket and tighten. Tighten screw in front brackets.
6. Install wood unit, with slides attached, into cabinets, engaging the product member slides into the cabinet member slides. Push the unit until it locks in place.

Toll Free: 1-888-883-5860
Fax: 1-877-639-7908
Email: Inquiries@ModularKitchenCabinets.com
Website: www.ModularKitchenCabinets.com

REV-A-SHELF



Modular Kitchen Cabinets